

KEY TO CABLE COLOURS

B—BLACK
D—DARK
G—GREEN

K—PINK
L—LIGHT
N—BROWN

O—ORANGE
P—PURPLE
R—RED

S—SLATE
U—BLUE
W—WHITE
Y—YELLOW

When cables have two code letters the first is the main colour, the second the tracer, i.e. RG—Red with Green

KEY TO CIRCUIT DIAGRAM (FIGURE 146)

1	Starter motor	37	Warning light, choke
2	Inspection sockets	38	Brake warning light and test button switch
3	Horn	39	Fuel gauge
4	Instrument illumination	40	Voltage stabiliser
5	Speedometer illumination	41	Stop lamp switch
6	Side lamp, R.H.	42	Heater motor, 2-speed
7	Side lamp, L.H.	43	Switch for heater motor
8	Convoy lamp	44	Windscreen washer motor
9	Tail lamp, R.H.	45	Windscreen wiper motor
10	Number plate illumination	46	Windscreen wiper/washer switch
11	Tail lamp, L.H.	47	Hazard and turnlight unit
12	Headlamp, main, R.H.	48	Warning light, turnlights
13	Headlamp, main, L.H.	49	Warning light, trailer
14	Warning light, main beam	50	Alternator, 16ACR
15	Headlamp, dip, R.H.	51	Cold start control warning light switch
16	Headlamp, dip, L.H.	52	Ignition coil
17	Turnlight, rear, R.H.	53	Mechanical fuel change-over switch
18	Turnlight, front, R.H.	54	Inhibitor socket for windscreen wiper motor
19	Turnlight, front, L.H.	55	Oil pressure switch
20	Turnlight, rear, L.H.	56	Distributor
21	Starter solenoid	57	Brake servo vacuum loss switch
22	Ignition and starter switch	58	Brake, dual system shuttle valve switch
23	Horn push	59	Fuel tank, R.H.
24	Panel light switch	60	Fuel tank, L.H.
25	Relay unit for infra-red switch	61	Stop lamp, R.H.
26	Lighting switch, 6 way	62	Stop lamp, L.H.
27	In-line fuse for heater	63	Stop lamp
28	Infra-red switch	64	Stop lamp
29	Headlamp flasher and dip switch	65	Auxillary
30	Relay unit for lights	66	Convoy, trailer
31	Battery, 12 volt	67	Tail light, trailer
32	Fuses	68	Earth
33	Hazard warning switch	69	Spare
34	Turnlight switch	70	Turnlight, trailer, R.H.
35	Warning light, ignition	71	Turnlight, trailer, L.H.
36	Warning light, oil pressure		

