


Fig. N1-14. Circuit diagram, 4 cylinder 'Regular', 'Long' and Station Wagon, Diesel models, negative earth, with headlamps mounted in front wings

- | | |
|---|--------------------------------------|
| 1 Batteries, two 6 volt | 28 Switch, stop lamp |
| 2 Warning light and resistor, heater plugs | 29 Switch, wiper motor |
| 3 Heater plugs | 30 Indicator unit, flasher |
| 4 Horn push button | 31 Switch and warning light, flasher |
| 5 Horn | 32 Dynamo |
| 6 Panel light, speedometer | 33 Warning light, dynamo |
| 7 Switch, panel light | 34 Warning light, oil pressure |
| 8 Panel light, instrument | 35 Warning light, fuel level |
| 9 Side lamp, RH | 36 Fuel gauge |
| 10 Side lamp, LH | 37 Temperature gauge |
| 11 Tail lamp, RH | 38 Wiper motor |
| 12 Tail lamp, LH | 39 Switch, oil pressure |
| 13 Headlamp, RH, dipped beam | 40 Fuel tank unit |
| 14 Headlamp, LH, dipped beam | 41 Temperature transmitter unit |
| 15 Headlamp, LH, main beam | 42 Stop lamp, RH |
| 16 Headlamp, RH, main beam | 43 Stop lamp, LH |
| 17 Warning light, headlamp main beam | 44 Socket, wiper lead |
| 18 Starter motor | 45 Front flasher, RH |
| 19 Switch, starter-heater plugs | 46 Rear flasher, RH |
| 20 Switch, lights | 47 Rear flasher, LH |
| 21 Switch, headlamp dip | 48 Front flasher, LH |
| 22 Inspection sockets | |
| 23 Fuse, A1-A2 (35 amp) | |
| 24 Fuse, A3-A4 (35 amp) | |
| 25 Feed, interior light | |
| 26 Regulator box | |
| 27 Voltage stabiliser, fuel gauge and water temperature gauge | |

Snap and Lucar connections —  —

Earth connections —  —

Cable colour code

B—Black P—Purple W—White R—Red N—Brown Y—Yellow U—Blue G—Green L—Light